

## Kit AHD de 8 Cámaras



### 8 PCS AHD CAMERA KIT

#### Features :

- 1\* 8ch AHD DVR
- 8\* HD AHD camera
- 2\* Power supply
- 8\* 18m cable for camera
- 2\* 4 in 1 splitter cable
- 1\* USB mouse
- HD-AHD KIT
- 8ch H.264 video compression
- Resolution system: embedded linux
- Realtime 8\* 960P recording and 8CH playback
- With HDMI/support PTZ/ P2P/E-cloud
- Support 1 pcs 4TB HDD



## Camera Technology data

Image Device	1/4" HD OMNIVISION OV9712 CMOS Sensor
TV System	PAL/NTSC
Total Pixels	1280(H) × 800(V) Approx. 1.024M Pixels
IR CUT	Yes
Active Pixel	1280*720
SYNC.	Internal
Resolution	720P
VIDEO OUT	1Vp-p,75ohm, BNC
Minimum Illumination	0 Lux ( When IR is on)
Auto compensation	Auto
IR LEDs	24 pcs IR LEDs
Lens	3.6 mm Lens
Electric Shutter	1/50s-1/50000s
S/N Ratio	>50dB
Day/Night	Auto(ICR) / Color / B/W
Power Supply	DC12V±10%
Waterproof	Indoor & Outdoor
Working temperature	-20°C~ +60°C
Storage Temperature	-20°C~ +70°C
Transmission distance	Over 500m via 75-3 coaxial cable

## AHD DVR Specification

Main processor	3520D
Video compression	H.264(High Profile),
Encode	4*AHD-M or 4CH 960H
Decode	1*720PAHD or 960H
Video input	Pure Analog : 4*720 AHD ,4*AHD-L / Hybrid :2*720PAHD (Analog)+2*720P (Network),/ Pure Network::4*720P,4*1080P,8*720P,8*1080P, 1*1080P
Audio compression	G.711A
Intercom	Support
Record mode	Manual>alarm>motion detection>timing
Playback Channels	4ch real time
Space occupation	960H:12~20G/ day*channel / 720P:20G~30G/ day*channel / Audio:691.2M/ day*channel
Backup mode	Network backup ,USB HDD, USB writer, SATA writer
Video input	8 BNC
Video output	1ch VGA,1ch HDMI
Audio input	1ch RCA
Audio output	1ch RCA
Alarm input	NO
Alarm output	NO
Network interface	RJ45 10M/100M Adaptive Ethernet port
PTZ control	One RS485,support multiple PTZ protocols
USB	2 USB ports
Hard disk	1 SATA (Each maximum support 4T)



- 1. 8\*18m HD Video cable for camera
- 4. 8\*screw set for camera
- 7. 2\*4 in 1 splitter cable

- 2. Power supply( for cameras)
- 5. 2\*3A Power adapter
- 8. QC passed card

- 3. USB mouse
- 6. 2\*Power plug
- 9. User manual